EVEREADY®

SMART Wi-Fi TIMER

User Manual

ios APP

Android APP

Scan QR code to download “eFamily cloud” or search in google play/ App store.
You may have to change the setting of device to authorize download.

Warning: - For Indoor use only.

Do not overload, risk of fire or electrocution

Product Features:

1.Support Wi-Fi 2.4 Ghz 802.11b/g/n Wireless network.
2.Status indicator.
3.Power consumption indicator (Optional)
4.Support remote/ local control through 2G/3G/4G/ Wi-Fi networks.

Product Specifications:

Voltage: AC 100-240V.
Current: 10A.
Rated frequency: 50/60 Hz.
Working Temperature: -10 C- 45C (14F- 113F).
Output; Current: **10A – Maximum 2200W – do not overload, risk of fire or electrocution**

INDOOR USE ONLY.

App Operation:

Scan the QR code on the User Manual to download the App, Open the App “eFamilyCloud”, click “Register”, and select your country code, if you use phone number,please click next step, and you will received a verification code. If you use email, please click next step and create a password.

Set your password with 6 to 20 alphanumerics
NOTE: Before device connection, it is required to reset the device

(See FAQ for reseting method)

See specific operation on << Operation Instruction>>

(Scan above QR code to download the complete manual instruction)

FAQ:

Q: What should I do if I cannot connect the Smart Wi-Fi timer?

A: a.Please check whether device is powered on.
b.Whether phone is connected to Wi-Fi, and check if your device is connected to the same Wi-Fi which your phone is connected.
c.Whether device is ready for configuration.
d.Make sure the password entered in App is correct when adding new device.

Q: How do I reset the device?

A: Power on device. Power off after 10s and then power on, hold the reset button for 5 seconds until indicator light is quickly flashing.

Q: I have accessed the device, but I cannot control electrical appliances, what should I do?

A: a. Check and ensure device/ appliance is plug in Smart WIFI timer.
b. Check whether your mobile phone has normal network access.minimum 3G signal.

Q: How do I connect Amazon Alexa,Google Home, or IFTTT with the eFamilyCloud app?

A: Please click "Profile"--"Third party access" to select your desired connection and follow the instructions in the app.

Warning:

1. Please do not use the device under humid, high temperature environment.
2. Please do not use the product in the bed sheets
3. Please do not connect to any household appliances over 10A.
4. For Indoor use only.
5. Do not overload, risk of fire or electrocution

Control eFamilyCloud devices with Alexa Instruction


1.Get your device ready

(1) Log in eFamilyCloud APP.
(2) First of all ,make sure you have added supported device in your eFamilyCloud account. Please click "ADD DEVICES"on the home page .


(3) Rename the device (Please use standard name such as、light、switch、my socket,) Please remember the name for next steps usage.

2. Connect your Echo to your eFamilyCloud System.


(1) Open Alexa APP, tap on the menu on upper left corner.




(2) Go to "Skills"




(3) Search for “eFamilyCloud” Skill in the search bar.




(4) Tap on "eFamilyCloud" Skill.




(5) Tap on "Enable" button.



(6) Enter your eFamilyCloud account information and tap on "Link Now" to link your eFamilyCloud account to your Amazon account.



(7) Your Amazon Echo is connected to your eFamilyCloud system now. Click "x" on the top right corner to close below page.



(8) Two Way to find your devices.

① Find devices on the Alex app; “Home” than “Smart Home” page and then click “Discover Devices”.

②.-Voice control to find devices.

3. Control eFamilyCloud devices with Alexa

Try out these phrases ({DeviceName} should be the name of your device):
Take light bulb as an example by the name of "light"
{DeviceName}:

(1) ON:"Alexa,turn on light {DeviceName}".when you hear response "OK" means control successfully
(2) OFF: "Alexa,turn off light {DeviceName}"
(3) Dimming:
①"Alexa,set light {DeviceName} to 80 percent"
②"Alexa,dim light {DeviceName} to 50 percent"
③"Alexa,dim light {DeviceName} by 100 percent"
(4) Color changing:
“Alexa,set light {DeviceName} to blue"

4. Notes:
(1) Make sure APP and device firmware update to the latest version
(2) Supported models: Wi-Fi light、socket、power strip.
(3) Please make sure internet well connected.

IMPORTANT: - Amazon, Alexa and all related logos are trademark of Amzon.com, Inc. or its affiliates.

© 2018 Energizer. Eveready and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by B&M Retail Ltd, L24 8RJ.
All other brand names are trademarks of their respective owners. Neither B&M Retail Ltd, L24 8RJ nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.