
HAMPTON TV UNIT

349509


45MINS

APPROXIMATE ASSEMBLY TIME




2 PERSON ASSEMBLY

FLOOR AREA
2.5MX2M




REQUIRED ASSEMBLY SPACE


REQUIRED ASSEMBLY TOOLS



SLOTTED SCREWDRIVER (Not Provided)



POZI SCREWDRIVER (Not Provided)




MODEL NAME:

HAMPTON TV UNIT

349509

NO.	PART LIST	QTY	NO.	PART LIST	QTY
①	TOP PANEL	1	⑧	BOTTOM SUPPORT BOARD	1
②	BOTTOM PANEL	1	⑨	BACK PANEL	1
③	SIDE PANEL	2			
④	UPRIGHT PANEL	1			
⑤	UPPER SHELF PANEL	1			
⑥	UPPER SHELF PANEL	1			
⑦	DOOR PANEL	2			

PARTS LIST




MODEL NAME:


HAMPTON TV UNIT

349509


HARDWARE LIST



18x 6x35mm	18x 15x10mm	18x 8x30mm	16x 4x12mm	2x 8x50mm	4x 4x18mm	4x 4x45mm
A	B	C	D	E	H	L
CAM BOLT	CAM LOCK	DOWEL	SCREWS	DOWEL	SCREWS	SCREWS



2x	4x	2x	5x	16x	6x
F	G	I	J	K	M
DOOR STOPPER	HINGE	HANDLE	FOOT NAILS	NAIL	STICKERS



1x

N

	MODEL NAME: HAMPTON TV UNIT 349509

Top Tips before you start!

1. Please check that all parts are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficent space and people (as indicated on page 1) to assemble your product safely
4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
6. During assembly please take care not to over-tighten any fittings, as this may damage the product.
7. Always place the product on a flat, steady and stable surface.
8. Do not sit or stand on the product. Do not use the product as a stepladder.
9. This product is intended for indoor, household use only as it is non industrial product.
10. Please do not kneel on any part of this product during assembly.

Care and Maintenance of your Furniture


- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Please do not place hot items (e.g. hot drinks) directly on to the wood surface.
- Please do not drag and pull your furniture.


MODEL NAME:

HAMPTON TV UNIT


349509


STEP 1





STEP 2







MODEL NAME:

HAMPTON TV UNIT


349509


STEP 3





STEP 4






MODEL NAME:

HAMPTON TV UNIT

349509


STEP 5




x2



STEP 6






MODEL NAME:

HAMPTON TV UNIT


349509


STEP 7





STEP 8







MODEL NAME:

HAMPTON TV UNIT


349509


STEP 9





STEP 10





MODEL NAME:

HAMPTON TV UNIT

349509

STEP 11

