COBERG


SOFA SIDE TABLE

ITEM CODE: 404879

Assembly Instructions


30 mins		FLOOR AREA 1Mx1M
APPROXIMATE ASSEMBLY TIME	2 PEOPLE ASSEMBLY	REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS



POZI SCREWDRIVER(Not Provided)

ASSEMBLED DIMENSIONS



Max. Loading: 10kg


COBERG SOFA SIDE TABLE

ITEM CODE: 404879

Assembly Instructions

NO.	PART LIST	QTY	NO.	PART LIST	QTY
①	TOP PANEL	1	④	MIDDLE PANEL	1
②	LEFT SIDE PANEL	1	⑤	BOTTOM PANEL	1
③	RIGHT SIDE PANEL	1			

PART LIST







COBERG SOFA SIDE TABLE

ITEM CODE: 404879

Assembly Instructions

HARDWARE LIST

P1 x8	P2 x8	P3 x4	P4 x8	P5 x1
		 M5 x 40mm	 M8 x 30mm	
Quick Fit	Cam-lock	Screw	Wood Dowel	Allen Wrench

P6 x4

Sticker

COBERG SOFA SIDE TABLE

ITEM CODE: 404879

Assembly Instructions

Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!

WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.

⚠ **CAUTION! RISK OF INJURY!** Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are secure firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 10kg onto the unit, otherwise there is a risk of injury and/or damage to the product
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.

COBERG SOFA SIDE TABLE


ITEM CODE: 404879


Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK








Quickfit head needs to be in centre

QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




COBERG SOFA SIDE TABLE

ITEM CODE: 404879

Assembly Instructions

STEP 1







P1 x 4



P2 x 4

STEP 2






M5 x 40mm
P3 x 4



M8 x 30mm
P4 x 4




P5 x 1


COBERG SOFA SIDE TABLE

ITEM CODE: 404879

Assembly Instructions

STEP 3





P1 x 4



P2 x 4




M8 x 30mm
P4 x 4


COBERG SOFA SIDE TABLE

ITEM CODE: 404879

Assembly Instructions

STEP 4





B&M Retail, L24 8RJ, UK
Homesavers, 5 Old Dublin Rd, Dublin, A94 K1H5
Made in China